

THE MULTI-DISC BRAKE IS A SPRING-APPLIED, HYDRAULICALLY RELEASED BRAKE. HYDRAULIC PRESSURE IS REQUIRED TO RELEASE OR "HOLD OFF" THE BRAKE. NORMAL OPERATION IS TO HAVE THE BRAKE PRESSURIZED IN THE RELEASED POSITION WITH THE VEHICLE HYDRAULIC SYSTEM RUNNING. ANY FUNCTION WHICH REDUCES THE HYDRAULIC SYSTEM BELOW THE RELEASE PRESSURE OF THE BRAKE WILL CAUSE THE BRAKE TO BE APPLIED.

CAUTION:

FOR CORRECT OPERATION, HYDRAULIC PRESSURE TO THE BRAKE MUST FALL TO ZERO PSI. ANY RESIDUAL BACK PRESSURE APPLIED TO THE BRAKE WILL DEGRADE FUNCTION AND MAY RESULT IN A HAZARDOUS CONDITION.

INSTALLATION INFORMATION:

1. ASSEMBLE ADAPTER PLATE TO GEARBOX USING TWO LUBRICATED 1/2" SOCKET HEAD CAP SCREWS. PLACE MOUNTING GASKETS ON BOTH SIDES OF THE ADAPTER BEFORE ASSEMBLY. TIGHTEN BOLTS TO 80-90 FT-LBS [108-122 Nm].
2. MOUNT BRAKE TO ADAPTER FLANGE USING TWO LUBRICATED GRADE 8 BOLTS 1/2-13 UNC-2A X 4" LONG. TIGHTEN BOLTS TO 80-90 FT-LBS [108-122 Nm]. IF NEEDED, BRAKE CAN BE ROTATED BY APPLYING HYDRAULIC PRESSURE TO PISTON INLET PORT.
3. MOUNT MOTOR TO BRAKE USING FOUR LUBRICATED 1/2" GRADE 8 BOLTS OR TWO LUBRICATED 3/8" GRADE 8 BOLTS. IF 1/2" BOLTS ARE USED, TORQUE TO 80-90 FT-LBS [108-122 Nm]. IF 3/8" BOLTS ARE USED, TORQUE TO 35-40 FT-LBS [47-54 Nm]. NOTE: THE SHAFTS MUST SLIDE TOGETHER FREELY. DO NOT USE THE BOLTS TO FORCE THE UNIT TOGETHER.
4. WITH MOTOR AND BRAKE BOLTED TOGETHER INTO POSITION, CONNECT INLET HYDRAULIC LINE. BRAKE INLET IS 1/4" TUBING, STRAIGHT THREAD O-RING BOSS (7/16-20 UNF).

BRAKE DISASSEMBLY INFORMATION:

1. DISASSEMBLE IN THE FOLLOWING ORDER: BOLTS (ALTERNATELY), POWER PLATE, GASKET, STATIONARY DISCS, ROTATING DISCS, PRIMARY DISC, TORQUE PINS, COMPRESSION SPRINGS, AND SPRING RETAINER.
2. FURTHER DISASSEMBLY IS NOT RECOMMENDED AND SHOULD NOT BE ATTEMPTED UNLESS NECESSARY TO REPLACE THE BEARING, THE SEAL, OR THE SHAFT.
NOTE: IF THE BEARING AND SEAL ARE REMOVED FOR ANY REASON, BOTH MUST BE REPLACED.
 - 2a. REMOVE SNAP RINGS AS NEEDED.
 - 2b. SEAL CAN BE REMOVED BY PRYING IT OUT WITH AN APPROPRIATE TOOL. TAKE CARE NOT TO DAMAGE THE BORE.
 - 2c. SHAFT CAN BE REMOVED BY PRESSING IT OUT WITH A SHOP PRESS.
3. REMOVE THE PISTON FROM THE POWER PLATE BY INTRODUCING LOW PRESSURE AIR (15 psi [1 BAR]) INTO THE HYDRAULIC INLET. MAKE SURE THE PISTON IS DIRECTED AWAY FROM THE OPERATOR. DO NOT REMOVE O-RINGS AND BACKUP RINGS FROM THE O.D. AND I.D. GROOVES OF THE PISTON UNLESS REPLACEMENT IS NECESSARY, BECAUSE THEY WILL BE DAMAGED.

ASSEMBLY INFORMATION:

IMPORTANT: THERE MAY BE MORE PARTS IN A SERVICE KIT THAN YOUR BRAKE REQUIRES. CHECK THE PARTS LIST CAREFULLY FOR THE EXACT QUANTITY. SPACE THE SPRINGS AS SHOWN ON THE SPRING ORIENTATION VIEW.


USE THE REVERSE OF THE DISASSEMBLY PROCEDURE WITH THE FOLLOWING NOTES AND ADDITIONS:

1. WORN AND DAMAGED O-RINGS AND BACKUP RINGS MUST BE REPLACED PRIOR TO RE-ASSEMBLY.
2. LUBRICATE THE PISTON BORE OF THE POWER PLATE, THE PISTON, AND THE O-RINGS WITH SYSTEM HYDRAULIC FLUID PRIOR TO RE-ASSEMBLY.
3. PISTON ASSEMBLY:
ASSEMBLE PISTON INTO POWER PLATE USING A SHOP PRESS. TAKE CARE NOT TO DAMAGE THE O-RING OR TEFLON BACKUP RINGS. VISUALLY ALIGN THE CENTER OF THE CUTOUTS IN THE PISTON WITH THE TORQUE PIN HOLES IN THE POWER PLATE.
CAUTION: THE DEPTH THE PISTON IS INSTALLED INTO THE POWER PLATE IS CRITICAL. THE SURFACE OF THE PISTON AT THE CUTOUTS MUST BE FLUSH TO 0.120 [3,05 mm] BELOW THE SURFACE OF THE POWER PLATE, OR PISTON MAY COCK RESULTING IN A COMPLETE LOSS OF BRAKING.
4. BEARING ASSEMBLY:
USE A SHOP PRESS TO PRESS THE BEARING ONTO THE SHAFT. PRESS ONLY ON THE INNER RACE OF THE BEARING. BEARING IS A SLIP FIT TO THE HOUSING.
5. LIP SEAL ASSEMBLY:
LIP OF SEAL MUST FACE TOWARD THE BEARING. SEE CUTAWAY VIEW FOR SEAL ORIENTATION DETAIL.
6. ROTATING, STATIONARY, AND PRIMARY DISC ASSEMBLY:
ROTATING DISCS MUST BE CLEAN & DRY. THE LINING MATERIAL AND MATING SURFACES OF THE STATIONARY DISCS MUST BE THOROUGHLY CLEAN AND FREE FROM DEBRIS. WORN OR SCARRED ROTATING DISCS MUST BE REPLACED.
7. INSTALL BOLTS IN THE POWER PLATE. TIGHTEN SEQUENTIALLY ONE TURN AT A TIME UNTIL POWER PLATE IS PROPERLY SEATED. TORQUE BOLTS TO 80-90 FT-LBS [108-122 Nm].



SERVICE KIT INFORMATION:

- BEARING KIT: PK - 1476 - INCLUDES SEALS, RETAINING RINGS, AND BEARINGS.
- STACK KIT: PK - 1436 - INCLUDES COMPRESSION SPRINGS, TORQUE PINS, PRIMARY, STATIONARY, AND ROTATING DISCS.
- O-RING KIT: PK - 1359 - INCLUDES O-RINGS, BACKUP RINGS, AND INTERNAL GASKET.
- GASKET KIT: PK - 1501 - INCLUDES EXTERIOR GASKET(S).

| ITEM | PART | DESCRIPTION | QTY |
|------|-------|--------------------|-----|
| 1 | 75502 | POWER PLATE | 1 |
| 2 | 76979 | HOUSING | 1 |
| 3 | 35875 | TORQUE PIN | 2 |
| 4 | 78010 | GASKET | 2 |
| 5 | 83376 | ADAPTER | 1 |
| 6 | 36384 | COMPRESSION SPRING | 11 |
| 7 | 36385 | COMPRESSION SPRING | 9 |
| 8 | 74554 | SPRING RETAINER | 1 |
| 9 | 76983 | LIP SEAL | 1 |
| 10 | 76977 | SHAFT | 1 |
| 11 | 78198 | RETAINING RING | 1 |
| 12 | 28284 | BALL BEARING | 1 |
| 13 | 74553 | PRIMARY DISC | 1 |
| 14 | 74771 | ROTATING DISC | 4 |
| 15 | 74552 | STATIONARY DISC | 4 |
| 16 | 75093 | GASKET | 1 |
| 17 | 27966 | BACKUP RING | 1 |
| 18 | 27777 | O-RING | 1 |
| 19 | 75109 | PISTON | 1 |
| 20 | 27808 | O-RING | 1 |
| 21 | 27967 | BACKUP RING | 1 |
| 22 | 29035 | BLEEDER | 1 |
| 23 | 74877 | WASHER | 4 |
| 24 | 73594 | HEX HEAD BOLT | 4 |
| 25 | 28435 | PROTECTIVE PLUG | 1 |
| 26 | 28863 | MAB GASKET | 1 |



SECTION A-A



NESTED SPRING ORIENTATION
NO SCALE